

Boss BHT4 Coding Instructions



Genuine BHT4



Compatible BHT4



Active BHT4

Programming Your Remote Into the Motor

- 1 Press either the Radio Set Button (overhead openers), or the Learn button (roller openers)
- 2 Push the button on your remote control that you wish to open the door with
- 3 Test the operation of your new remote

Clearing The Codes From Your Motor

- 1 For overhead openers, hold down the Radio Set Button for 5 seconds
- 2 For roller openers, turn power off to the motor, and hold down the Learn button. Turn the unit back on (whilst still holding Learn down) and continue to hold for 10 seconds
- 3 Test your remote to make sure it no longer operates your motor

Watch us on



PLEASE NOTE

Boss Openers have recently updated the BHT remote control, formerly known as the 2211-L (TX) to 303RTX. There is no difference in the remote controls, and both operate in the same manner.