

Switching Instructions

The grey Auto Openers v2 remote can switch between three different modes of operation, being the Boss BHT-4, Gliderol TM-305c or the Avanti / Superlift encryptions.

Once you have swapped over the remote to your required mode of operation, please follow the steps to program a remote to the opener as you normally would.



Gliderol TM305c

1. Press and hold Buttons 3 and 4 until the LED turns solid.
2. Release Button 4, do not let go of button Button 3..
3. Press Button 2 once. The LED will flash once.
4. Release Button 3. The remote is now set to Gliderol.
5. Following the instructions for the original TM305c, program the remote to the motor

Steel Line / Boss BHT-4

1. Press and hold Buttons 3 and 4 until the LED turns solid.
2. Release Button 4, do not let go of button Button 3.
3. Press Button 2 twice. The LED will flash twice.
4. Release Button 3. The remote is now set to Boss BHT-4.
5. Following the instructions for the original BHT-4, program the remote to the motor

Superlift / Avanti TX4

1. Press and hold Buttons 3 and 4 until the LED turns solid.
2. Release Button 4, do not let go of button Button 3.
3. Press Button 2 three times. The LED will flash three times.
4. Release Button 3. The remote is now set to Avanti / Superlift.
5. Following the instructions for the original TX4, program the remote to the motor